

BOWMONK AFM2 TIME SETTING INSTRUCTIONS

1. Power on the unit (pressing reset)
2. When the unit displays AFM2 Ready press "Enter"
3. While in editing mode press the "down arrow" once
4. On the Configuration Screen press "Enter"
5. Password: SAPPAS (S, A, Print, Print, A, S)
6. Advanced Setup press "Enter"
7. Password Protect, No Flashing press "Enter"
8. External Trigger, No Flashing press "Enter"
9. LCD Backlighting, Yes Flashing press "Enter"
10. Fine Slope, No Flashing press "Enter"
11. Miles Per Hour, Yes Flashing press "Enter"
12. Results in % G, Yes Flashing press "Enter"
13. Delay In Average, No Flashing press "Enter"
14. Get Peak Reading, Yes Flashing press "Enter"
15. Trim Parameters, Press **"UP ARROW"**
16. Adjust Clock, press "Enter"
17. Adjust minutes by using up and down arrows then hit "Enter"
18. Adjust hours by using the up and down arrows then hit "Enter"
19. Hit RESET Button, Unit should display AFM2 Ready and the correct time.